


INDEX	NAME		CATALOGUE NUMBER	DRAWING
ADAPTER (COAXIAL) FOR STANDARD BOILERS AND WATER HEATERS WITH CLOSED COMBUSTION CHAMBER				
T 9000 00 69 00	Elbow 90° – adapter with revision, measuring points and collar on the boiler	φ 60/100	KKT422/60	
T 9000 00 67 00	Adapter with water trap with measuring points and collar on the boiler	φ 60/100	ADK 505/60	
T 9000 00 52 00		φ 80/125	ADK 505/80	
ADAPTER (COAXIAL) FOR CONDENSING BOILERS				
T 9000 01 14 00	Elbow 90° – adapter with revision, measuring points and collar on the boiler	φ 60/100	KKR 425/60	
T 9000 01 15 00	Elbow 90° – adapter with revision, measuring points and collar on the boiler	φ 80/125	KKR 425/80	
T 9000 01 12 00	Adapter with measuring points and collar on the boiler	φ 60/100	ADK 512/60	
T 9000 01 13 00	Adapter with measuring points and collar on the boiler	φ 80/125	ADK 512/80	
ADAPTER (SEPARATE) FOR CONDENSING AND STANDARD BOILERS				
T 9000 00 53 00	Flue gas adapter with water trap with measuring points and collar on the boiler (standard boilers)	φ 60 na φ 80	ADS 507/80	
T 9000 01 11 00	Flue gas adapter with water trap with measuring points and collar on the boiler (condensing boilers)	φ 80	ADS 512/80	
T 9000 00 54 00	Air adapter with measuring points and collar on the boiler	φ 80	ADP 503/80	