

Basket strainer FMK



The FMK basket strainer is designed to capture solid pollutants carried by water in central heating installations and heating networks. Their use allows for the proper operation of heat exchangers, pumps, boilers and other system devices, preventing the deposition of contaminants that remain in the filter basket and are easy to remove. Purification of the medium stream is a process of mechanical separation of solid particles (e.g. gravel, particles originating from pipe corrosion) in the filter element, which is a removable basket. The basket is made of perforated stainless steel and a 500 µm filter mesh. The body of the basket strainer is made of powder-coated steel. Product is equipped with a manual air vent and a drain valve. Additionally, to ensure the capture of ferromagnetic impurities, the device can be equipped with a magnetic insert.

Technical data:

Material:steelMax pressure:6 barMax temperature:90°CFilter insert:500 μmPressure norm of flanges:PN 10/16Connections:

boiler side: flange DN 65 for FMK+ 150-DN 65

flange DN 80 for FMK+ 250-DN 80 **flange DN 100** for FMK+ 300-DN 100

installation side: flange DN 65 for FMK+ 150-DN 65

flange DN 80 for FMK+ 250-DN 80 flange DN 100 for FMK+ 300-DN 100


Туре	Flow [m³/h]	Power at ΔT 20 °C	Catalog number
Basket strainer FMK+ 150 - DN 65 with additional equipment, with insulation, painted	9,00	130	T 9260 14 19 00
Basket strainer FMK+ 250 - DN 80 with additional equipment, with insulation, painted	12,00	280	T 9260 14 22 00
Basket strainer FMK+ 300 - DN 100 with additional equipment, with insulation, painted	20,00	470	T 9260 14 23 00

Magnetic insert for basket strainers FMK




The magnetic insert is used to capture metal particles, preventing contamination from settling in the installation.

Туре	Catalog number
Magnetic insert $\frac{1}{2}$ " for basket strainers FMK 150 - DN 50, DN 65	T 9260 14 31 00
Magnetic insert ¾" for basket strainers FMK 250 - DN 80, FMK 300 - DN 100	T 9260 14 32 00




Dimensional diagram

FMK 150 -	EN414 250	
DN 65	FMK 250 - DN 80	FMK 300 - DN 100
DN 65	DN 80	DN 100
150	180	180
250	420	420
168	273	324
430	550	550
490	600	600
350	510	510
7	23	33
	DN 65 150 250 168 430 490 350	DN 65 DN 80 150 180 250 420 168 273 430 550 490 600 350 510



In case of assembly basket strainer with hydraulic separator in the presented configuration brackets included in set with basket strainer should be used.

Straight distance connector for basket strainer FMK



Straight distance connector helps install the basket strainer in pump group systems.

Catalog	699062	699063	699064
DN	DN 65	DN 80	DN 100
L	350	510	510

Туре	Catalog number
Straight distance connector DN 65 (L-350mm) for FMK 150 - DN 65 with screws and gasket EPDM DN 65	T 9260 14 21 00
Straight distance connector DN 80 (L-510mm) for FMK 250 - DN 80 with screws and gasket EPDM DN 80	T 9260 14 26 00
Straight distance connector DN 100 (L-510mm) for FMK 300 - DN 100 with screws and gasket EPDM DN 100	T 9260 14 27 00

Basket strainer operation

Maintenance of the basket strainer consists of periodic cleaning of the filter basket, magnetic insert and draining the sediment from the lower part of the tank. The frequency of cleaning depends on the degree of water contamination and the type of contamination. Basket strainer have been designed to make their operation as simple as possible. Cleaning the mesh filter is done by removing the basket filter and opening the drain valve at the bottom of the device.

Filter cleaning

Cleaning should take place after 24 hours of operation after installation (cleaning from sediment) and periodically approximately every 6 weeks. Cyclical maintenance involves cleaning the filter basket and removing the magnetic cartridge, as well as removing impurities by opening the drain valve.

Filter basket maintenance:

- close the shut-off valves,
- remove the insulation,
- drain the water from the basket strainer using the drain valve with the basket strainer vent valve open,
- open the cut-off valve at the outlet from the sludge filter for a moment, thanks to which the filter will be rinsed and the contaminants will flow out through the drain valve,
- close the drain valve,
- close the vent valve,
- open the closing collar of the basket strainer,
- remove the basket and rinse out the sediment and other unwanted elements in the basket,
- reinstall the filter basket,
- close the closing collar of the basket strainer,
- open the supply shut-off valve,
- vent the basket strainer installation,
- open the valve after the basket strainer,
- install insulation.



Basket strainer cannot be used with electronic devices.



The device must be installed by a qualified person.

User manual

Basket strainer FMK



Terms of warranty

- Termet S.A., hereinafter referred to as the Guarantor, grants the Buyer a guarantee for the proper operation of the device described in detail in the Warranty Card. The warranty card is recognized valid if it has legible and correctly filled in boxes containing the date of sale, date of installation, seal and signature of the Seller.
- The warranty period for the device is 24 months from the date of sale, but not longer than 30 months from the date of introduction to distribution. The warranty is valid only on the territory of the Republic of Poland. 2
- The warranty covers the removal of all kinds of technical defects of the equipment, which are the result of its normal operation in accordance with the instruction manual and will be 3. revealed during its validity period. The warranty does not apply to consumables or other accessories. Under the warranty granted, the Guarantor is not responsible for the loss of expected benefits and costs incurred by the Purchaser resulting from the use or inability to use this equipment.
- 4. In order to exercise the warranty rights, it is required to deliver the defective equipment together with this warranty to the point where it was purchased or to another p
- The condition for accepting a complaint during the warranty period is to deliver the equipment in a complete state with a valid warranty card, a copy of the proof of purchase, and a detailed description of the fault prepared by the Buyer. To process the complaint, it is also necessary to provide basic data identifying the Buyer, his exact address, contact telephone number, email address. 5.
- 6
- telephone number, email address.
 The claimant is obliged to deliver the equipment in a package secured with adhesive tape. In the absence of the factory packaging, the complained equipment should be delivered for repair by the Buyer in a way that ensures safe transport. In the case of improper packaging, the Buyer is responsible for the risk of damage that may result in transport. The costs related to the provision of proper, safe packaging shall be borne by the Purchaser.

 Defects revealed during the warranty period will be removed by the Guarantor free of charge. The choice of the method of fulfilling the obligations arising from the warranty granted to the Buyer belongs to the Guarantor, who may remove the defect by repairing or replacing the damaged part, or by replacing the device in its entirety. The replaced device and defective components become the property of the Guarantor. 7.
- 8. The warranty does not cover venting the installation and other activities provided for in the instruction manual, which the user is obliged to perform on his own and at his own
- In the event of an unjustified complaint, the Guarantor may charge the Buyer with the costs of the expertise, restoring the functionality of the product and the costs of transporting the product. An unjustified complaint is considered to be the return of functional equipment to the service address or, in the event of damage due to the reasons indicated in point 15, 16, 17, 18 9.
- 10
- below.

 In the event of replacement of the equipment with a new one, the equivalent of the parts missing or damaged by the Purchaser and the cost of their replacement shall be deducted.

 The guarantor will take steps to ensure that the repair is made within 14 days from the date of delivery of the device to the service. In justified cases, this period may be extended, but the Guarantor will exercise due diligence to remove the defect as soon as possible.

 If the complaint is not accepted, the Guarantor shall notify the Buyer about it within 14 days from the date of delivery of the device to the service. 11.
- 12.
- 13.
- The Guarantor is not liable for non-performance of obligations under the guarantee due to unforeseeable circumstances beyond his control, such as lightning or power surges, etc.

 The Guarantor is responsible for defects resulting only from reasons inherent in the sold product. The warranty does not cover damage caused after its sale for other reasons, in particular:

 -mechanical, thermal, chemical damages and improper operation of the product resulting from these damages and defects caused by them,

 - damage resulting from non-compliance with the typical or specified in the operating instructions rules for using the product, using the product contrary to its intended use and other damage caused by the Buyer,
 - damage resulting from damage to the system in which the equipment was installed or used,
 - damage resulting from failure to perform activities that the user is obliged to perform in accordance with the operating instructions, e.g. periodic cleaning, maintenance, adjustment, etc. damage and defects caused in transport, damage and defects caused by random events, independent of the operating conditions (fire, flood, incorrect power supply voltage, etc.). claims for technical parameters of the product, provided that they are consistent with the manufacturer's data.
- The buyer loses the warranty rights in the event of 15.

 - removal or obliteration of product serial numbers, any attempts at repairs, modifications or structural changes made by persons not authorized by the Guarantor,
 - loss of the warranty card or making changes and deletions in it by unauthorized persons
- using non-original parts or materials.
 The warranty does not cover consumables and elements subject to natural wear and tear (e.g. seals, etc.), 16
- 17 The product delivered to the service should be clean. The service technician may refuse to accept a dirty, contaminated product or clean it at the buyer's expense
- 18. Products are maintenance free. They should be installed, commissioned, operated and dismantled only by suitably qualified and trained personnel. Changes and modifications made by unauthorized persons may cause hazards and are prohibited for safety reasons.
- 19
- Warranty for the product sold consumer goods do not exclude, limit or suspend the buyer's rights resulting from the non-compliance of the goods with the contract.

 The rights under this warranty are vested only in the Buyer indicated in the warranty document, who confirmed acceptance of its terms by signing. Warranty rights are not transferable to 20.
- In matters not covered by the terms of this Guarantee Card, the relevant provisions of Polish law shall apply 21

Between 7 am and 3 pm (Mon-Fri) information about failures can be reported by phone (74) 85 60 801 or by e-mail: serwis@termet.com.pl

ns specified by the manu	cturer in the instruction manual and it is	not possible to use it as intended, an	nd the reason for the
er:			
	Date of i	ntroduction to sale:	
	Date of installation and	a seal and signature of the installe	er:
r d	ns specified by the manufa and accept the terms of t	s specified by the manufacturer in the instruction manual and it is and accept the terms of this warranty. I consent to the processing	its completeness and stated that the equipment is not burdened with a manufacturing defect. The equipment is specified by the manufacturer in the instruction manual and it is not possible to use it as intended, and accept the terms of this warranty. I consent to the processing of my personal data for the purpose manufacturers of this warranty. I consent to the processing of my personal data for the purpose manufacturing defect. The equipment is not possible to use it as intended, and a land accept the terms of this warranty. I consent to the processing of my personal data for the purpose manufacturing defect. The equipment is not possible to use it as intended, and accept the terms of this warranty. I consent to the processing of my personal data for the purpose manufacturing defect. The equipment is not burdened with a manufacturing defect. The equipmen